

Cartridges aluminum empty

25 mm Diameter

ALUMINUM CANS 25mm Diam - ECCO

ALUMINUM CANS 25 MM DIAM - ECCO

Features:

Empty alumin cans for flexible materials and thermoplastic acrylics*Compatible with Valpast, Duracetal, Flexite, TCS, CFS, etc

Older Flexite Injection System:

(1 + 3/32 Inch diameter) Small (1.5 Inches), Medium (2.5 Inches), Large (3.5 Inches), Extra- Large (4.5 Inches)

New Flexite Model F-3 Injection System, Valplast, Inductor KFT, TCS, and

Dentsply-FRS Injection System, GFM and CFS system:
(1 Inch diameter)

Small (1.75 Inches),

Medium (2.75 Inches) 70mm

Large (4 Inches), 98mm

Extra Large (4.75 Inches) 115mm

Dental D, Pressing J-100 & J-200, Flexiplast & Polypress Injection Systems:

(21.7 mm diameter)9 Gram-Small (2 inches), 16

Gram-Medium (3.5 Inches), 20 Gram-Large (4.5 Inches)

Powder Management:

Humidity must be taken away from the powder, not from the cartridge.

All cartridges must be dried before making the 2 hours at 70 C 158 F (Thi is the most conservative)

(Can be done in a regular horizontal small oven/toaster)

If cartridge explodes, or opens before it takes the complete holding time, it is because of the stocking conditions of the cartridge.

Their is only one solution for this; open the cartridge, dry the powder and make a new cartrige.



Code	Name	Price	+
200148	ECCO - Empty Aluminum Cartridge with Cap included x100 - Large size - 25.4mm/1in...	US\$ 145.73	+Info
200149	ECCO - Empty Aluminum Cartridge with Cap included x100 - Medium size - 25.4mm/1i...	US\$ 156.97	+Info

Catalog Index / Indice

25 mm Diameter 1